


# Little Port Walter, SE05-13

Center of map at 56° 23.48' N Lat., 134° 37.44' W Lon.

## Geographic Response Strategies for Southeast Alaska Subarea, Zone 5



This is not intended for navigational use.



EX01c viewed from the west.



EX01d viewed from the south.



EX01e viewed from the south.

**Legend**

- Free-oil Recovery
- Exclusion Booming
- Protected-water Boom
- Bears in Area, Guards Recommended

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE05-13-01 	<b>Little Port Walter</b> a. Lat. 56° 23.05'N Lon. 134°38.76'W b. Lat. 56° 22.85'N Lon. 134°42.23'W c. Lat. 56° 22.68'N Lon. 134°43.90'W d. Lat. 56° 23.41'N Lon. 134°43.07'W e. Lat. 56° 23.62'N Lon. 134°39.65'W	<b>Exclusion</b> Exclude oil from entering the identified creeks in Little Port Walter.	Deploy anchors and boom with skiffs (class 6).  Place the identified amount of protected-water boom in front of each creek in a chevron pattern to exclude oil from entering the creek.  Tend throughout the tide.  a. 400 ft. b. 300 ft. c. 550 ft. d. 300 ft. e. 200 ft.	<b>Deployment</b> <b>Equipment</b> 17500 ft. protected-water boom 9 ea. small anchor systems 10 ea. anchor stakes <b>Vessels</b> 1 ea. class 3 2 ea. class 6 <b>Personnel/Shift</b> 7 ea. vessel crew <b>Tending</b> <b>Vessels</b> 1 ea. class 3 1 ea. class 6 <b>Personnel/Shift</b> 3 ea. vessel crew	Vessel Platform	Via marine waters  Chart 17333	Fish: coho, chum, pink, dolly varden  Birds: waterfowl concentration  Habitat: gravel beach, marsh, sheltered rocky shore, exposed tidal flats  Human uses: subsistence, commercial fishing, high recreational use	Vessel master should have local knowledge.  Hatchery operation may provide support with logistics and equipment.  Bears are present in the area. Bear guard required.  Consult with Incident Command to ensure ADFG-Title 16 and ADNR-Title 41 permits have been obtained.  Consult the Site Selection Matrix for cultural resources designation.  Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics.  Site surveyed: not surveyed  Tested: not yet
SE05-13-02 	<b>Little Port Walter</b> Nearshore waters in the general area of:  Lat. 56° 23.27'N Lon. 134°38.26'W	<b>Free-oil Recovery</b> Maximize free-oil recovery in the offshore & nearshore environment Little Port Walter depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Hoonah.  Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Port Alexander-10nm-via marine waters	Via marine waters  Chart 17333	Same as SE05-13-01	Vessel master should have local knowledge.  Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the SE AK Sub-Area Contingency Plan: [http://www.dec.state.ak.us/spar/perp/plans/scp\\_se.htm](http://www.dec.state.ak.us/spar/perp/plans/scp_se.htm).